


for your purchase

90-Day money-back guarantee for any reason.

1-Year warranty for quality-related issues.

If you get defective items or are not 100% satisfied; please have no hesitation to contact us at anngrowy@hotmail.com.

And we will try best to help you.



FOLDING A POPUP TENT




1. Hold the two sides of the portable dressing room and push them inward, then fold the dressing room in half.



2. Bend the top of the dressing room downward.



3. Grab the two arch sides of the dressing room with one hand




4. Push the top of the dressing room inward the other hand.



5. The dressing room will automatically turn into a flat, round shape.



6. Place the dressing room into the carrying bag.



Installation Video, Please Search in YouTube: Folding the Privacy Pop Up Tent How to Fold a Popup Changing Tent.